




The Filter Selector / BIAS_SHIFT continue'd




Turn the lower knob clockwise then the LED on the lower knob lights up in DarkGreen, which means the knob is activating the mode "EXT_VALin with EXT_VAL_PCH".



Turn the lower knob clockwise then the LED on the lower knob lights up in Indigo, which means the knob is activating the mode "EXT_VALin with EXT_VAL_VOL".



Turn the lower knob clockwise then the LED on the lower knob lights up in Violet, which means the knob is activating the mode "EXT_VALin with EXT_VAL_BTH".



Turn the lower knob clockwise then the LED on the lower knob lights up in Brown, which means the knob is activating the mode "NoEXT_VAL with KIL_EXT_VAL".